

Mounting Bracket Instructions

Part Number UC-0848

1. Wrap band around cylinder and feed through the opening in the mounting bracket
2. Hold bracket against cylinder and pull band tight
3. Tighten set screw using fingers until band fits snug around the cylinder
4. Cut excess band as close to the bracket as possible (as shown) using shears
5. Using allen key, continue to tighten the set screw until the exposed edge of the band is completely retracted into the bracket housing. (Do not exceed 3 in-lb torque. Damage to bracket and/or cylinder may occur.)
6. Slide switch into bracket and tighten screw

