

## Mounting Chart for Clippard Valves

The following chart gives the necessary spacing required between the shoulder of the valve and the base of the adapter. Two 1.6 mm spacers are furnished with each adapter.

**Manual Push Mushroom**



Part No.	Description
PL-P2M-R	Red
PL-P2M-G	Green
PL-P2M-B	Black

Manual Push “In”.  
Spring Return.


**Spring Return Twist 45°**



Part No.	Description
PL-T2T-B	Black

Turn clockwise and hold for “In”.  
Release for spring return.  
Black only.

**Push Key Push Button**



Part No.	Description
PL-P4K-B	Black

Manual push “In”.  
Spring return. Turn key counter-clockwise to lock “Out”; clockwise to unlock. Key withdrawable locked or unlocked.

**Maintained Twist 90°**



Part No.	Description
PL-T3T-B	Black

Turn clockwise to latch “In”. Turn counterclockwise to release.  
Black only.

**Flush Push Button**



Part No.	Description
PL-P2F-R	Red
PL-P2F-G	Green
PL-P2F-B	Black
PL-P2F-Y	Yellow

Manual Push “In”.  
Spring Return.

**Extended Push Button**



Part No.	Description
PL-P2E-R	Red
PL-P2E-G	Green
PL-P2E-B	Black
PL-P2E-Y	Yellow

Manual Push “In”.  
Spring Return.

**Key Twist 90° Maintained**



Part No.	Description
PL-T3K-B	Black
PL-K3K-B	Black

(PL-T3K-B) Turn key clockwise to latch “In”. Turn key counterclockwise to release. Key withdrawable in both positions. Black only..

PL-K3K-B same as PL-T3K-B except key is withdrawable in “Out” position only.

**Push Key Mushroom**



Part No.	Description
PL-L4M-R	Red

Manual push “In”. Automatic latches “In”. Turn key clock-wise to release. Spring return. Key withdrawable “Out” position only. Red only.