



# VÁLVULAS SOLENOIDES MAXIMATIC®

## Válvulas de 2 vías

No. de serie	Estilo	Entrada	Puertos		Función	Cv	Flujo a	
			Salida	Escape			100 psig	
MME-2PDS	Asiento	1/8" NPT	1/8" NPT	1/8" NPT	2/2	0.12	6.7	scfm
MME-2QDS	Asiento	1/4" NPT	1/4" NPT	1/4" NPT	2/2	0.12	6.7	scfm
MME-2SDS	Asiento	1/8" NPT	1/8" NPT	1/8" NPT	2/2	0.05	2.3	scfm

## Válvulas de 3 vías

MME-3PDS	Asiento	1/8" NPT	1/8" NPT	1/8" NPT	3/2	0.12	6.7	scfm
MME-3QDS	Asiento	1/4" NPT	1/4" NPT	1/4" NPT	3/2	0.12	6.7	scfm
MME-3SDS	Asiento	1/8" NPT	1/8" NPT	1/8" NPT	3/2	0.05	2.3	scfm
MME-31NES	Corredera	#10-32	#10-32	#10-32	3/2 NC	0.58	27	scfm
MME-31PES	Corredera	1/8" NPT	1/8" NPT	1/8" NPT	3/2 NC	0.67	31	scfm
MME-32QES	Corredera	1/4" NPT	1/4" NPT	1/8" NPT	3/2 NC	0.89	49	scfm
MME-33WES	Corredera	3/8" NPT	3/8" NPT	1/4" NPT	3/2 NC	1.68	93	scfm
MME-34ZES	Corredera	1/2" NPT	1/2" NPT	1/2" NPT	3/2 NC	2.79	171	scfm
MME-31NEE	Corredera	#10-32	#10-32	#10-32	3/2	0.58	27	scfm
MME-31PEE	Corredera	1/8" NPT	1/8" NPT	1/8" NPT	3/2	0.67	31	scfm
MME-32QEE	Corredera	1/4" NPT	1/4" NPT	1/8" NPT	3/2	0.89	49	scfm
MME-33WEE	Corredera	3/8" NPT	3/8" NPT	1/4" NPT	3/2	1.68	93	scfm
MME-34ZEE	Corredera	1/2" NPT	1/2" NPT	1/2" NPT	3/2	2.79	171	scfm

## Válvulas de 4 vías

No. de serie	Estilo	Entrada	Puertos		Función	Cv	Configuración de la corredera				
			Salida	Escape			Flujo a 100 psig	Centro cerrado	Centro escape	Centro presión	
MME-41NES	Corredera	#10-32	#10-32	#10-32	5/2	0.58	27	scfm			
MME-41PES	Corredera	1/8" NPT	1/8" NPT	1/8" NPT	5/2	0.67	31	scfm			
MME-42QES	Corredera	1/4" NPT	1/4" NPT	1/8" NPT	5/2	0.89	49	scfm			
MME-43WES	Corredera	3/8" NPT	3/8" NPT	1/4" NPT	5/2	1.68	93	scfm			
MME-44ZES	Corredera	1/2" NPT	1/2" NPT	1/2" NPT	5/2	2.79	171	scfm			
MME-41NEE	Corredera	#10-32	#10-32	#10-32	5/2	0.58	27	scfm			
MME-41PEE	Corredera	1/8" NPT	1/8" NPT	1/8" NPT	5/2	0.67	31	scfm			
MME-42QEE	Corredera	1/4" NPT	1/4" NPT	1/8" NPT	5/2	0.89	49	scfm			
MME-43WEE	Corredera	3/8" NPT	3/8" NPT	1/4" NPT	5/2	1.68	93	scfm			
MME-44ZEE	Corredera	1/2" NPT	1/2" NPT	1/2" NPT	5/2	2.79	171	scfm			
MME-41NEEC	Corredera	#10-32	#10-32	#10-32	5/3	0.50	23	scfm	●		
MME-41PEEC	Corredera	1/8" NPT	1/8" NPT	1/8" NPT	5/3	0.50	23	scfm	●		
MME-42QEEC	Corredera	1/4" NPT	1/4" NPT	1/8" NPT	5/3	0.67	49	scfm	●		
MME-43WEEC	Corredera	3/8" NPT	3/8" NPT	1/4" NPT	5/3	1.00	72	scfm	●		
MME-44ZEEC	Corredera	1/2" NPT	1/2" NPT	1/2" NPT	5/3	1.68	93	scfm	●		
MME-41NEEP	Corredera	#10-32	#10-32	#10-32	5/3	0.50	23	scfm			●
MME-41PEEP	Corredera	1/8" NPT	1/8" NPT	1/8" NPT	5/3	0.50	23	scfm			●
MME-42QEEP	Corredera	1/4" NPT	1/4" NPT	1/8" NPT	5/3	0.89	49	scfm			●
MME-43WEEP	Corredera	3/8" NPT	3/8" NPT	1/4" NPT	5/3	1.00	72	scfm			●
MME-44ZEEP	Corredera	1/2" NPT	1/2" NPT	1/2" NPT	5/3	1.68	93	scfm			●
MME-41NEEE	Corredera	#10-32	#10-32	#10-32	5/3	0.50	23	scfm		●	
MME-41PEEE	Corredera	1/8" NPT	1/8" NPT	1/8" NPT	5/3	0.50	23	scfm		●	
MME-42QEEE	Corredera	1/4" NPT	1/4" NPT	1/8" NPT	5/3	0.89	49	scfm		●	
MME-43WEEE	Corredera	3/8" NPT	3/8" NPT	1/4" NPT	5/3	1.00	72	scfm		●	
MME-44ZEEE	Corredera	1/2" NPT	1/2" NPT	1/2" NPT	5/3	1.68	93	scfm		●	