

Mounting Chart for Clippard Valves

The following chart gives the necessary spacing required between the shoulder of the valve and the base of the adapter. Two 1.6 mm spacers are furnished with each adapter.

Flush Push Button



| Part No. | Description |
|-----------|-------------|
| P22-P2F-R | Red |
| P22-P2F-G | Green |
| P22-P2F-B | Black |
| P22-P2F-Y | Yellow |

Manual Push “In”.
Spring Return.

Extended Push Button



| Part No. | Description |
|-----------|-------------|
| P22-P2E-R | Red |
| P22-P2E-G | Green |
| P22-P2E-B | Black |
| P22-P2E-Y | Yellow |

Manual Push “In”.
Spring Return.

Automatic Push/Turn Mushroom



| Part No. | Description |
|-----------|-------------|
| P22-L3M-R | Red |
| P22-L3M-G | Green |
| P22-L3M-B | Black |

Manual push “In” Latches
“In”. Turn clockwise to un-
latch. Spring return.

Maintained Twist 90°



| Part No. | Description |
|-----------|-------------|
| P22-T3T-B | Black |

Turn clockwise to latch
“In”. Turn counterclockwise
to release.
Black only.

Spring Return Twist 45°



| Part No. | Description |
|-----------|-------------|
| P22-T2T-B | Black |

Turn clockwise and hold for
“In”.
Release for spring return.
Black only.

Manual Push Mushroom



| Part No. | Description |
|-----------|-------------|
| P22-P2M-R | Red |
| P22-P2M-G | Green |
| P22-P2M-B | Black |

Manual Push “In”.
Spring Return.

Key Twist 90° Maintained



| Part No. | Description |
|-----------|-------------|
| P22-T3K-B | Black |
| P22-K3K-B | Black |

(P22-T3K-B) Turn key
clockwise to latch “In”.
Turn key counterclockwise
to release. Key withdra-
wable in both positions.
Black only.

Push Key Mushroom



| Part No. | Description |
|-----------|-------------|
| P22-L4M-R | Red |

Manual push “In”. Auto-
matic latches “In”. Turn
key clock-wise to release.
Spring return. Key with-
drawable “Out” position
only. Red only.

