

Fill & Bleed Valves



Fill and Bleed Valves may be used to pressurize or "fill" a chamber or bladder by depressing the toggle in one direction and then de-pressurize or "bleed" that same chamber or bladder by depressing the toggle in the other direction. Toggling back and forth between the inlet and exhaust provides a fine adjustment of the required pressure in the chamber or bladder.

Air Flow	125 l/min @ 50 psig; 210 l/min @ 100 psig - 125 l/min @ 3.4 bar; 210 l/min @ 7 bar
Data Sheet	Data Sheet
Force for Full Stem Travel	8 oz. Nominal
Included Item(s)	Nut & Lockwashers
Input PSI	120 max
Material, Body	Brass Body, Stainless Steel Stem & Spring
Material, Seals	Nitrile
Medium	Air
Mount	#5/8-32 Thread. Two 0.171" mounting holes in body
Operating Pressure	120 psig max. (8.3 bar)
Product Line Brochure	Mechanical Valves
Weight (lbs.)	0.2100

