Taking the Guesswork Out of Pneumatic Control

Here's a step-by-step approach to efficiently designing systems that work right the first time—and without electricity.

method for decades. But conditions sometimes exist that prohibit the use of electronic controls. For example, magnetic resonance imaging machines emit strong electromagnetic fields that are incompatible with strong ferrous metals and external electronic fields. Strong radiofrequency fields can interfere even with hard-wired electronic controls.

Furthermore, equipment operating in close proximity to explosives or fuels and other volatile fluids must be explosion-proof—a requirement that adds considerable bulk and expense to control components. These conditions may not be the norm, but any one of them can leave control system designers wondering what alternatives are available.

This is where pneumatic control provides a subplates. surprisingly wide array of solutions. Modular air-logic systems are often a good bet when a compact, economical unit is a must. They typically consist of a series of valves mounted onto standard manifold subplates.

Such systems speed assembly and piping, and all interconnections between valves and controls in the circuit are machined into the manifold subplate. This cuts design and installation time, reduces the number of fittings, and eliminates potential leak points, piping, and routing errors.

For instance, compared with discrete air-valve control systems, a modular system provides:

- proven, reliable design.
- lower component costs.
- simple plumbing and troubleshooting.
- lower air consumption.
- no air locks.
- a smaller total package.

Compared to electrical-relay control, a modular system offers:



Pneumatic sequence controllers
provide step-by-step system operation. Sequence valves and other
components mount to the manifold
subplates


- an explosion-proof system with no danger of burnouts.
- lower power consumption.
- lower costs by eliminating solenoids and relays.
- a single air supply.
- no heat buildup.


Only a few manufacturers offer modular, manifold-mounted pneumatic control systems. For instance, Clippard offers a pneumatic programmable controller—a sequential controller that provides step-by-step system operation. It consists of a clear acrylic manifold for mounting sequence valves and other such components in a compact, efficient package.

The system is designed to automatically generate feedback signals to initiate the next step when an operation finishes. Many

types of sensors can generate feedback signals, including limit valves, proximity sensors, pressure sensors, Hall-effect switches, back-pressure cylinder sensors, and manual pushbuttons.

START OPTIONS





System shutoff prevents accidental machine operation.

Feedback signals provide positive, safe operation. If no signals are sent (due to a component failure, missing or jammed parts, and so on), the sequence stops and an indicator pinpoints where to troubleshoot. Internal interlocks prevent out-of-sequence feedback signals.

A pneumatic output signal at each step actuates air-piloted devices, including power valves, hydraulic valves, pressure switches, and other components that may control air cylinders. The last sequence valve resets the system to repeat the cycle of operations.



Now Available

SC Hydraulic Engineering introduces its new portable test cart. This compact mobile design offers many popular features found on our standard power units.



SC Hydraulic's Newest Addition 90 Series Portable Test Cart

- Mobile self contained power unit
- Air operated No electricity needed
- Pressures up to 65,000-psi with 100-psi air drive
- Available with a 5 or 10 gallon stainless steel reservoir
- Compatible with most fluids
- Available with all 10-series pumps
- Air drive controls, pressure gauges and valves included
- Used in:

 Hydrostatic testing
 Burst testing
 Water-jet blasting
 Hydraulic press operation
 Hydraulic cylinder & valve actuation


*Contact factory for gauges over 60,000 psi

SC Hydraulic Engineering Corporation
1130 Columbia Street . Brea, California 92821 . USA
Phone (714) 257-4800 . Fax (714) 257-4810 . Email info@schydraulic.com

-ax (714) 257-4810 . Email info@scnydraulic www.SCHydraulic.com

SUNNY SIDE UP, OVER EASY or SCRAMBLED?!!!

Yet another choice for hydraulic cylinder positioning from ROTA!!





Wellington Street, Bury, Manchester, BL8 2BD, UK



Rota Engineering Ltd

UK Tel: +44 (0) 161 764 0424 US Tel: 972 359 1041 info@rota-eng.com www.rota-eng.com



DESIGN BASICS

Modular systems can contain just a few valves or dozens, with many built-in functions to permit a systematic approach to circuit design. As with any control system, it is essential to outline system requirements to save time and reduce the chances of missing a critical step.

Designers must also have a clear understanding both of the sequence of operations (including pressure, temperature, filtration, and other operating conditions) and the control requirements (including manual, automatic, start, stop, etc.). As a final check of circuit operation, consider proper actuation during all conceivable events. This includes startup, shut down, loss of air, panic stops in mid-cycle, restarts in mid-cycle, and control during any other event likely to occur.

PROGRAMMING GUIDELINES

After defining the overall functions and requirements of a system, configure the system following some basic guidelines. First, label all components in the pneumatic circuit. At Clippard, we recommend labeling each cylinder with a letter of the alphabet, starting with A. The same holds for air motors and other controlled devices. Label the valve controlling the cylinder with the same letter.

Label the pilot of the valve that extends the cylinder (or activates a device) with a plus symbol, and the pilot of the valve that retracts the cylinder (or turns off a device) with a minus symbol. Label the limit sensor the cylinder rod strikes with the letters LV (limit valve), the letter of the cylinder, and position of the sensor for extending or retracting. LVA+, for example, would mean the limit valve of an extended cylinder A.

Second, list in detail every sequence of operation. This includes the action or control that initiates a step, what function takes place during that step, and the limit sensor that ends the operation. Note what position all actuators are in for every step. An example of a simple two-cylinder sequence is shown in the *table* (available exclusively in the online version of this article).

Third, select components for the control system. Modular systems offer great flexibility because users can incorporate multiple options when selecting sequence valves. For instance, in the "Two-cylinder sequence" example (online exclusively), five steps require five sequence valves.

A basic valve could be used for each step, or you could choose valves with special features. For example, the first two steps could use a valve that provides a sequence reset lock if the start button is held down or if the limit valve LVA+



MULTIPLE FUNCTIONS SM1 SM2 SM3 SM4 Out Out Out Out Phone Power valves

A shuttle valve to the pilot of a power valve lets a function actuate twice during a sequence.

is locked down. Reset lock means the sequence will not reset to bypass the valve being actuated.

After choosing components, assemble fittings and modular valves into the subplate. Connect the air supply and lines from the limit valves and electrical connections from the Hall-effect sensors to the inlet connections. Finally, connect air lines from the outlet to the air pilots of the power valves.

CHANGING OPERATIONS

Modular systems can be quickly tailored to meet specific requirements. Sequence conditions can be altered or adapted to the application by using different control modules. Here's a look at some common options.

Start options—If the application demands an input for each cycle of operations, use a pushbutton input signal and a sequence valve that provides a reset lock if the button is held actuated. If continuous cycling is required, use a selector or toggle valve at the input of the first step along with a valve that permits continuous cycle sequences. For applications requiring choosing between one cycle or continuous cycling, add a selector valve that determines the type of operation.

Manual jog—This control option lets users jog (step-by-step) through the machine sequences. One way to do this is to control air flow to the limit valves, with the jog control a pushbutton or spring-return selector. If held actuated, the sequence continues until released.


Another method for manual-jog con-

trol is to use a binary-trigger circuit that controls the input to the sequence circuit. This approach requires actuating the jog signal for each step. A delay-out valve resets the binary trigger when there are an odd number of sequence steps.

Reset—This control, when actuated, returns the sequence to the start position. Reset can also place power valves in a home position. A reset circuit should only be used when the control is in manual mode.



GO TO HYDRAULICSPNEUMATICS.COM



Backpressure sensing indicates cylinder position without limit valves. backpressure diminishes at the pilot port of the NO three-way valve, letting a spring shift the valve to send a pneumatic signal to the next step. If the system requires a delay, substitute a delayout module for the three-way valve.

MIKE KETTERING is technical sales manager at Clippard Instrument Laboratory, Cincinnati. For more information, including circuit design assistance, call (513) 521-4261, or visit www.clippard.com.

response when activated.

System shutoff—These controls turn off the main air supply. This prevents harming people or product from accidental machine operation. If the system has large power valves, a piloted three-way main supply valve can control a specific machine section. When electrical circuits are part of the system, an air-piloted pressure switch ensures the system has electric power only if the air is on.

Multiple outputs—When two (or more) functions start with the same step, connect the output from that sequence step to both power valves.

Multiple functions—Functions that actuate twice during the sequence call for the system to connect a shuttle valve (OR function) to the pilot of the power valve.

Multiple inputs—When two functions actuate at the same time, a piloted three-way valve (AND function) ensures both functions are complete before the next step begins.

Delays—Applications requiring a delay before a step can use a delay-in module between the limit valve and the input to the step being delayed.

Backpressure sensing—Many air-cylinder applications cannot use mechanical limit valves for sensing because of physical interference, temperature extremes, or other conditions. A method called backpressure sensing indicates cylinder position without limit valves. For example, as a cylinder retracts, it creates a backpressure behind the piston. Restricting exhaust air at the control valve further increases pressure and slows return of the cylinder rod.

This backpressure holds the pilot down on a normally open (NO) three-way valve. When the cylinder fully returns,





Go from Receiving Directly to Your CNC Machine

Reduce Cycle Time Up To 25%

TCI Machine-Ready Manifold Blanks are custom made to order from one to thousands with quick turnaround. Delivering tolerances as close as +/- .0005" dimensionally and .0002" flatness, squareness, and parallelism with a surface finish of 16 – 25 RMS; Machine-Ready Blanks arrive deburred, clean and ready to load directly into your CNC machining center.

Call today to discuss your next job; we can provide you a 'next day' dimensional sample with your production quote. **800-234-5613**.

Save On:











www.tciprecision.com/manifolds

