



C • I • L
COMMUNICATIONS



Clippard GNV Series Needle Valves Now Available!

Cincinnati, Ohio -- Needle Valves are used to control the rate of flow in a pneumatic system by controlling flow in both directions. Material enters the input port, travels through an adjustable orifice and out the output port. Clippard's new GNV series is available with 1/8", 1/4" and 3/8" port sizes with flow rates up to 60 scfm at 100 psig. Mounting options include direct and in-line, as well as cartridge styles. Adjustment is achieved by either a recessed slot or knurled knob.

- Provide bidirectional flow control
- Rotating input allows 360° positioning
- Rugged and compact design
- Multiple mounting options
- 360° rotating ports
- Ideal for use with Clippard push-quick fittings

For more information about these needle valves or any of Clippard's other quality pneumatic products, call 513-521-4261 or visit www.clippard.com.

Clippard Instrument Laboratory, Inc.
7390 Colerain Avenue | Cincinnati, OH 45239
877-245-6247 | 513-521-4261
www.clippard.com

#