



## Flow Rate vs. Set Point Pressure @ 100 psig Supply Pressure


- Find the required flow rate in the graphs below.
- Determine the desired set point pressure.
- With a suggested pressure drop of <15 psig, determine which FRL size provides the required flow rate.




**MMFRL-1 & MMFRLS-1 Series**




**MMFRL-2 & MMFRLS-2 Series**



**MMFRL-3 & MMFRLS-3 Series**



**MMFRL-4 & MMFRLS-4**



**MMFRL-5 & MMFRLS-5 Series**

