


Subplate and Fitting Installation

The next step is to install the fittings into the R-101/R-101-M5 subplates using the octoport, octoport port coding, and pneumatic circuit diagrams. Generally, 1/16" hose is used for pilot ports and their adjoining lines and 1/8" hose are for supply lines and cylinders.


Looking at the Two-Hand, No-Tie-Down circuit:

1. Valve RV-1 has fitting [11752-5](#) (#10-32 to 1/16" I.D. hose fitting) installed in ports 4 and 8
2. Fitting [11752-4](#) (#10-32 thd. to 1/8" I.D. hose fitting) installed in ports 1 and 2 because port 1 is the main air supply for the circuit and port 2 is the outlet.
3. On valves V-1 and V-2, fitting [11752-5](#) was installed in both the inlet and outlet of each valve because both valves are used for pilot actuation of valves RV-1 and RV-2.



STEP FIVE

4. Being in a pilot line, the inline fixed orifice air choke N-1 was fitted with an [11752-5](#) on one end and a [UTO-2](#) universal "L" fitting on the other.



STEP SIX

Connecting Hose

With the fittings installed, the circuit is ready for hose. The color coding we use at Clippard is quite simple. Red hose is used for all supply lines. For all other hose as many different colors as possible are used in order to facilitate circuit trouble shooting.


1. Supply lines - Red hose
2. The 1/16" I.D. fittings require [URH1-0402](#) hose
3. The 1/8" I.D. fittings require [URH1-0804](#) hose
4. The main supply line was fitted with a [MIQC-CB4](#) which can be attached to any of the MJQC valve bodies.

Note: The MJQC series is not compatible with the MQC series.

STEP SEVEN

Modular Valve Hook-Up

The final assembly step is installing the modular valves and mounting gasket to the subplates.



Hose and barb sizes were picked with this particular application in mind. Both may vary to meet your needs. Feel free to contact our facility for technical support.